



## PRODUCT GROUP # 17 ROOF VENT FLASHING

# Roof Vent Flashings



### 'B' SERIES EPDM ROOF VENT FLASHINGS

		MIN.	SKID
039011	B 1-1/2" FLASHING 20" X 20" APRON	12	504
039021	B 2" FLASHING 20" X 20" APRON	12	504
039031	B 3" FLASHING 20" X 20" APRON	12	504
039041	B 4" FLASHING 20" X 20" APRON	12	504



### 'A' SERIES ALUMINUM ROOF VENT FLASHINGS

		MIN.	SKID
1713011	A 3P RV FLASHING 18" X 18" APRON	12	
1713021	A 4P RV FLASHING 18" X 18" APRON	12	
1771051	A 3PH HIGH DOME RV FLASHING for ABS DWV 20" X 20" APRON	12	144
1771061	A 4PH HIGH DOME RV FLASHING for ABS DWV 20" X 20" APRON	12	144
1771071	A 3CH HIGH DOME RV FLASHING for COPPER DWV 20" X 20" APRON	12	



### 'M' SERIES MULTI-SIZE PLASTIC BASE ROOF VENT FLASHINGS


		MIN.	SKID
1781700	M 1-1/4" - 3" (BASE 11" X 15") DWV FLASHING	20	
1781702	M 3" - 4" (BASE 12" X 15") DWV FLASHING	20	



### 'H' SERIES HARD PLASTIC BASE ROOF VENT FLASHINGS

		MIN.	SKID
1797001	HB 1-1/2" (BASE 18" X 18") THERMOPLASTIC FLSH.	10	480
1797002	HB 2" (BASE 18" X 18") THERMOPLASTIC FLSH	10	480
1797003	HB 3" (BASE 18" X 18") THERMOPLASTIC FLSH	10	480
1797004	HB 4" (BASE 18" X 18") THERMOPLASTIC FLSH	10	480

### WATERLINE Flashings - How To Use



Make sure roof is clean and free from any major protrusion before roof covering is installed.

No tar, asphalt-based roof cement or "pitch" should be applied to the collar portion of any EPDM or Thermoplastic flashing.

At the discretion of the installer, silicone sealant can be applied over all exposed nails or staples.

Silicone sealant can also be applied to the underside of the base to increase sealing power to the roof and is recommended in areas where frequent or heavy precipitation is common.

Place correct size WATERLINE flashing over vent stack with angle facing down slope of the roof. Push firmly to base of stack until flashing lies flat on the roof. Flashing size should be equivalent to pipe diameter size (i.e. 1.5" flashing for 1.5" pipe, 2" flashing for 2" pipe size, etc...).

Using corrosion resistant nails or staples, secure the top of the flashing (the end closes to the crest of the roof) at each corner and along the sides at 4"-6" intervals to secure flashing to the roof. One nail or staple in each bottom corner is appropriate. The top of the flashing will be covered one-quarter to one-half of the way down with roofing shingles. The bottom edge of the flashing should overlap the shingles beneath it so it shed, not traps, water.

WATERLINE Plastic flashings are designed to fit roof angles from flat to 45 degrees.